


www.aucilla.com 574-234-9036

Bearings Units: Assembly



PART NO.	A	В	C
LS-526	1 5/8"	1 5/16" to 1 3/8"	5/16"
LS-626	1 5/8"	1 5/16" to 1 3/8"	3/8"